

Installation material INDISPENSABLE



Maroufle
with felt
VO157



Isopropyl
alcohol
VO187



Cutter Pro
VO101

Batch of installation material Wrapping VO216



Cloth
VO269



Heat gun
VO240



Installation video
AVAILABLE



1 Preparing the bodywork

i Application temperature: between +15°C and +25°C

Installation away from dust and wind. We recommend that you put your car in a sheltered place the day before fitting, to avoid the bodywork getting cold.

Spray isopropyl alcohol solution (VO187) onto a micro-fibre cloth and clean the bodywork and all its nooks and crannies thoroughly, using circular movements.



2 Preparing the covering

Place the covering on the surface to be covered without removing the protective film.

💡 Use magnets (VO218) to hold the film in place

Cut the covering with the ergonomic cutter (VO199), leaving a 10 cm margin around the application surface.



3 Applying the wrapping

Remove part of the paper liner (about 20-30 cm) and fold it under the film.

Apply the covering without the liner to the bodywork, stretching it out as much as possible

Completely remove the remaining protective liner and pull the film so that there are as few creases as possible.

Peel off and stretch the wrapping over the workpiece, applying even tension.

Press from the centre outwards in regular strokes, carefully following the shape of the bodywork.

💡 If necessary, peel off the wrapping to re-stretch it and cover with adhesive.

⚠️ Caution: Be sure to mark the edges of the bodywork.



4 Finishes

Once the surface has been properly covered, trim off the excess covering.

⚠️ Using a new cutter blade, press it against the outer edge of the bodywork to retain a few millimetres of wrapping around the edges.

Remove excess wrapping.

Fold back the few millimetres of covering by heating with the heat gun to prevent any delamination.

💡 Use the mini-screwdriver (VO228) to access hard-to-reach returns.

Finish the application by heating the entire wrapping with a heat gun to finalise the activation of the adhesive.

i To fix the adhesive, the wrapping must reach 90°C.



👍 The installation is now complete!

⚠️ Avoid taking the vehicle outside for 2 days after the covering has been applied.

